

ARCHITECTURAL **GRATES + DRAINS**



65TiTDi

Tile Insert Drain

Stormtech is the only linear drainage system available with full
Greentag and Watermark certification across our complete product range.

Telephone 1300 653 403 | **Web** stormtech.com.au





ARCHITECTURAL
GRATES + DRAINS



65TiTDi

Tile Insert Drain



Code 65TiTDi


Range Threshold

Grate Style Ti

Category Made-to-Length

Channel Material Stainless Steel

Steel Grade 316



Grates longer than 1500mm supplied in sections.
Tile Inserts longer than 1200mm supplied in sections.
Channels over 3000mm supplied in sections with joiner.

The 65TiTDi is a Threshold Drain for door track with sub sill tray featuring our 65mm wide Tile Insert.

For sliding and Hinged doors.

Featuring a linear stainless steel grate with concealed channel section connecting sill and sub-sill for door tracks and thresholds.


Allows door sills to be drained while having internal and external floor surfaces with no step down.

Please be aware that depending on the installation environment, for a pool installation or close to a surf beach, you may need to have your stainless steel grates electropolished.

SPECIFICATIONS + DIMENSIONS

Channel Width	75mm
Channel Depth	Adjustable
Length(s)	As Required
Outlet Size	N/A

STORMTECH COLOUR FINISHES



Electroplate finishes subject to natural variation with time and local environment.

PRODUCT APPLICATIONS

Aged / Health Care Drainage
Balcony Drainage
Commercial Drainage
Multi-Residential Drainage
Special Needs Drainage
Threshold Drainage

Suspended Slab Drainage

Copyright © Stormtech Pty Ltd. Patent 733361. Drawings not to scale, please use dimensions shown.




Visit **stormtech.com.au**
for tools + inspiration.


Phone **1300 653 403**

Email **info@stormtech.com.au**

65TiTDi Linear threshold Drainage System



- * The entire door track and 65TiTDi are set in above and separate to waterproofing. Therefore waterproofing must be completed first.
- * Install the door track sub-sil.
- * When installing the 65TiTDi, the tray needs to be slightly deeper than the lowest part of the Sub-sil.
- * Standard installation sequence generally has the door track sub-sil in place before the drain. Therefore the tray may need to be slightly deeper than lowest part of the sub-sil to allow the drain channel to slide underneath the sub-sil.
- * Refer to;
AS1428 Design for Access and Mobility
AS4654 for waterproofing



Visit **stormtech.com.au**



StormtechTM

22 Norfolk Avenue, South Nowra, NSW 2541 Australia

Phone 1300 653 403 Email info@stormtech.com.au

